




Sony Cyber-shot DSC-W55 LCD Screen Replacement

This guide will show you how to replace the LCD screen of the Sony Cyber-shot DSC-W55.

Written By: Eddie Lo



INTRODUCTION


We will explain the steps needed in order to replace a LCD screen.



TOOLS:



- [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Battery





- Slide the battery cover in the direction the arrow points.
- Pull the battery cover towards you.

Step 2



- Flick the blue switch for the battery to pop out.
- Remove the battery from the camera.

Step 3 — Back Case





- Using the Phillips #00 Screwdriver, remove the two screws from the back case.

- Remove that panel.

⚠ Careful for falling pieces.

Step 4




- Remove the screw with a Phillips #00 Screwdriver from the right side of the camera (with '3x optical zoom' engraved on the side panel).
- Remove that panel.

Step 5



- Remove the screw using the Phillips #00 Screwdriver from the bottom the camera, closest to the back cover.

Step 6



- Gently remove the back cover.


⚠ It may be a bit stiff, so use some force to remove it. Proceed with caution.

Step 7 — Front Case




- Remove the screw using a Phillips #00 Screwdriver on the left side (where the "3x optical zoom" panel use to be).

Step 8





- Remove the small screw using a Phillips #00 Screwdriver on the bottom of the camera attached to the front cover.
- Gently remove the front cover.
- ⚠ Put a little force to pop off the case. Proceed with caution.

Step 9 — Lens




- Flip the black secure locks off. Tweezers may be necessary.
- Detach the two orange cables.

Step 10





- Gently pull the lens container out of the camera.

Step 11 — Motherboard - First Half





- Remove the black screw using a Phillips #00 Screwdriver on the motherboard.

Step 12






- Remove the two orange cables on the top of the motherboard with tweezers.
- Lift the motherboard out of its slot.

Step 13




- For the AV port, detach the bottom orange cable.
 - For the LCD screen, detach the top orange cable on the right side of the motherboard.
 - For the motherboard, detach all the orange cables.
- ⚠ Careful not to damage the red, white, and black wires when lifting the board.

Step 14 — LCD Screen




- Verify the orange cables from the motherboard are removed from the LCD screen.
- Lift the LCD screen off the hinge.

Step 15



- Verify that the LCD screen is attached to the chip on the back on the camera.
- Remove the dial from the back of the camera. It pops right off very easily.
- Remove the screw using a Phillips #00 Screwdriver from the camera.

Step 16



- Remove the orange cable that is attached between the top of the camera and the chip. It should slide straight out with a little bit of force.
- Remove the chip and the LCD screen now from the camera.
- The chip may need a slight upward tug with a fingernail or tweezers.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-29 12:38:25 PM.